### **WORK INSTRUCTION**

Title: Minor Repair of ICV/OCV Locking Ring Surfaces (burrs, dings, and nicks)

Instruction No. CH.14 Rev. 0, January 2002

Page 1 of 3

Approved for Use by: <u>Michael R. Brown</u> Effective Date: <u>January 2002</u>

# Applicable Drawings:

- 2077-500SNP (Sheet 8) TRUPACT-II Packaging SARP Drawings
- 707-SAR (Sheet 10) HalfPACT Packaging SARP Drawings

### SARP Requirements:

Chapter 8.0, Section 8.2.3.2. As required.

### **Tools Required:**

- Lifting Equipment
- Lid Stands

# Spare Parts Required:

None

### Materials Required:

- Unused 400 to 600 Grit Emery Cloth
- · Denatured Alcohol or equivalent
- Lint-Free Rags

# Safety Requirements:

Safety will be observed in accordance with site requirements.

#### Prerequisite Conditions:

ICV/OCV lid(s) must be removed to gain access to locking lug surfaces.

#### **Instruction Steps:**

 This instruction is not required to be attached to the Maintenance Record but may be used as a checklist during performance of maintenance.

# ☐ ICV or OCV Locking ring lug(s)

- 1.0 Using alcohol and lint-free rags, thoroughly clean area to be repaired.
- 2.0 Using emery cloth, remove any burrs and restore lug to original profile.
- 3.0 For larger burrs, use a fine cut file, then Emory cloth to remove file scratches and restore surface to 125 micro-inch finish or better.
- 4.0 Clean repaired area to remove any residue.
- 5.0 Using Work Instruction CH.14, Form 1, record locations where repairs were made.

**Instruction No. CH.14** 


Rev. 0, January 2002

Page 2 of 3

Verification Requirements:

- 1.0 Work performed is described on maintenance record.
- 2.0 Work instruction is listed on maintenance record.
- 3.0 Data sheet (Work Instruction CH.14, Form 1) is attached to maintenance record.

Attachment 1, Form 1 - ICV/OCV Lid and Body Locking Ring Surfaces
Packaging S/N:\_\_\_\_\_\_ Job. No.\_\_\_\_\_



ICV LID		ICV BODY		OCA FID		OCV BODY	
Loc.	<b>√</b> *	Loc.	✓*	Loc.	<b>√</b> *	Loc.	<b>√</b> *
1.		1.		1.		1.	
2.		2.		2.		2.	
3.		3.		3.		3.	
4.		4.		4.		4.	
5.		5.		5.		5.	
6.		6.		6.		6.	
7.		7.		7.		7.	
8.		8.		8.		8.	
9.		9.		9.		9.	
10.		10.		10.		10.	
11.		11.		11.		11.	
12.		12.		12.		12.	
13.		13.		13.		13.	
14.		14.		14.		14.	
15.		15.		15.		15.	
16.		16.		16.		16.	
17.		17.		17.		17.	
18.		18.		18.		18.	

Denciencies/adjustments note	d on Maintenance Record
QA:	Date:
Other:	Date: